



1854284

X-Sherwood Console

Parts List

A.	Top Assembly	1 pc
B.	Bottom Frame	1 pc
C.	Glass Shelf	1 pc
D.	Spindles	6 pcs
E.	Feet	6 pcs

- * Please make sure that you have all the parts indicated above before you begin assembly of this item.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.

Assembly Instructions

1. **Attach Spindles (D)** Put the Top Assembly (A) upside down on a soft surface. Align the exposed threads of Spindles (D) with the pre-threaded holes in the corner blocks of Top Assembly (A). Tighten by turning in a clockwise direction. See Illustration #1.
2. **Attach Bottom Frame (B)** Put the Bottom Frame (B) upside down. Align the pre-drilled holes in the Bottom Frame (B) with the pre-threaded holes in the Spindles (B). Insert the threads of Feet (E) through the pre-drilled holes and tighten by turning in a clockwise direction. See Illustration #1.
3. **Attach Glass Shelf (C)** Put the item assembly upright. Slant the Glass Shelf (C) among the Spindles (D). Put the Glass Shelf (C) on the Bottom Frame (B) carefully. See Illustration #2.




Illustration #1




Illustration #2